



Wireless Smart Plug SP1



Introduction

Package List: Smart Plug SP1 (×1) User Guide (×1)



Note: The sensor interface is a 3.5 mm audio jack.

Indicator Status & Operations

- When the indicator flashes alternately yellow and blue, it means the device is in the setup mode.
 - When the indicator is constantly blue, the device is powered on and the network is connected.
 - When the indicator is constantly yellow, the device is powered on but the network is disconnected.
 - When the indicator is off, the device is powered off.
 - When the indicator flashes blue, the device is resetting to default settings.
 - When the indicator flashes yellow, it means there are hardware errors.
- ⏻ Press the power button once to turn on/off the device.
- ⏻ Press and hold the button for 5 seconds to enter the setup mode.
- ⏻ Under “setup mode” , press the button three times in quick succession to reset the device.

Quick Start on Mobile Phone

STEP 1.

Launch the App and log in. Please make sure your phone's Bluetooth is enabled and then click "+" to add a device.

STEP 2.


Enter device WiFi setup mode: Plug the socket into the power supply, then press and hold the button for 5s until the indicator light flashes alternately yellow and blue. Follow the instructions on APP to complete the setup.

⚠ If the setup fails, please make sure that WiFi is 2.4 GHz and the password is entered correctly.

Mobile Data* Setup

STEP 1.

Insert a Nano-SIM card in the correct direction as instructed.




STEP 2.

Launch the App and log in. Please make sure your phone's Bluetooth is enabled and then click "+" to add a device. Please follow the instructions on APP to complete the setup process.

* Text marked with asterisk means the feature depends on the specific model purchased.

Sensor Connection

Plug the external sensor into Smart Plug.
(sensors need to be purchased separately)



Warranty Information

This device is warranted to be free of defects in materials and workmanship for a period of up to one year from the original purchase date.

The following situations are not covered by the warranty:

- ① Issues arising after the warranty period has ended.
- ② Malfunction or damage caused by improper handling or not operating the device according to the instructions.
- ③ Accidental or man-made product damage.
- ④ Natural wear and aging of materials.
- ⑤ Failure or damage caused by unauthorized removal of the product.
- ⑥ Failure or damage caused by *force majeure*.
- ⑦ Other faults or damage not caused by product design, technology, manufacturing, quality, etc.